



















ITEM NAME / NOM D'ITEM: ROCKY ARM CHAIR

ITEM # / NO.ITEM: 100528/100529/100530/101683/101684


## PARTS LIST / LISTE DES PIÈCES

(1)	(2)	(3)	(4)	(5)
 <p>×1</p>	 <p>×1</p>	 <p>×1</p>	 <p>×2</p>	A. M8 x 60MM  x2
				B. Ø8MM  x6
				C. M5  x1
				D. Ø8 X 18MM  x2
				E. Ø10 X 40MM  x4
				F. WOODEN CAP  x6
				G. M8 X 80MM  x4
				H. Ø4 X 50MM  x2
				I. PASTE PAD  x4
				J. L - BARCKET  x2
K. Ø4 X 20MM  x4				
L. Ø8MM  x6				


## ASSEMBLY INSTRUCTIONS / INSTRUCTIONS D'ASSEMBLAGE




III



IV



V



For missing parts or damaged parts, please call /  
Pour pièce manquante ou endommagée, veuillez appeler:

USA, Canada and Mexico : (866)798-6663

AI-V6-221104