






ITEM NAME/ NOM D'ITEM: DECO ACCENT CHAIR
ITEM#/NO.ITEM: 101851/101852

PARTS LIST/LISTE DES PIÈCES


(1)	(2)	(3)
 x1	 x4	A.  M8x30mm x12 B.  M6 x1

ASSEMBLY INSTRUCTIONS/ INSTRUCTIONS D'ASSEMBLAGE


I



II



III



For missing parts or damaged parts, please call/
 For pièce manquante ou endommagée, veuillez appeler:

USA, Canada and Mexico: (866) 798-6663

AI-V2-230208